

DVD Player

On DVD players with more than one video connection, connecting them to the TV can be done using any of the following options. Using more than one is unnecessary. Note that the stereo **audio** connection remains the same in all cases.

Using the **Composite** video (option 1) connection requires a single RCA cable and provides good video quality. Using the **S video** (option 2) connection requires a single S video cable and provides better video quality. Using the **Component** (option 3) video connection requires three RCA cables and provides the best video quality.

