

DVD Recorder

Combine either **To DVD** option with either **From DVD** option.

On DVD players with more than one video connection, connecting them to the TV can be done using any of the following options. Using more than one is unnecessary. **Note that the stereo audio connection remains the same in all From DVD options but 4.**

Using the **Composite** video (Option 1) connection requires a single RCA cable and provides good video quality. Using the **S video** (Option 2) connection requires a single S video cable and provides better video quality. Using the **Component** (Option 3) video connection requires three RCA cables and provides the best video quality. The RF/VHF (Option 4) connection requires no stereo audio connection and provides lesser quality video than option 1-3.

* TV should be tuned to Video channel for all connections but Option 4 (channel 3 or 4).

To DVD Option 1

To DVD Option 2

